

Übersetzungstabelle KZ

Getrieberad	Achsrad	Überhältnis	Getrieberad	Achsrad	Überhältnis
14	28	0,5000	16	25	0,6400
15	29	0,5172	18	28	0,6429
14	27	0,5185	15	23	0,6522
15	28	0,5357	17	26	0,6538
14	26	0,5385	19	29	0,6552
16	29	0,5517	16	24	0,6667
15	27	0,5556	18	27	0,6667
14	25	0,5600	19	28	0,6786
16	28	0,5714	17	25	0,6800
15	26	0,5769	18	26	0,6923
14	24	0,5833	16	23	0,6957
17	29	0,5862	19	27	0,7037
16	27	0,5926	17	24	0,7083
15	25	0,6000	18	25	0,7200
17	28	0,6071	19	26	0,7308
14	23	0,6087	17	23	0,7391
16	26	0,6154	18	24	0,7500
18	29	0,6207	19	25	0,7600
15	24	0,6250	18	23	0,7826
17	27	0,6296	19	24	0,7917
14	22	0,6364	19	23	0,8261